





BRUNING 401195 411003-1



2" REINFORCING LUMBER AND COLLAR TIES LAGBOLTED TO RAFTERS. USE A FLAT STEEL WASHER UNDER THE LAGBOLT HEAD.

ROOF REINFORCING LUMBER (SHOWN SHADED) MUST BE PLACED DIRECTLY UNDER CENTER OF MOUNTING FEET.



TOP VIEW

NOTES

1. TO INSURE SAFETY, NO INSTALLATION, ROOF OR WALL, SHOULD BE ATTEMPTED WITHOUT A LOCAL PROFESSIONAL STRUCTURAL ANALYSIS.
2. IT IS THE PURCHASER'S RESPONSIBILITY TO VERIFY THAT HIS INSTALLATION IS ADEQUATE TO WITHSTAND ALL LOADS IMPOSED BY HIS MOUNT AND ANTENNA.
3. LOCAL ZONING AND/OR BUILDING CODES AND INSURANCE COMPANIES MAY REQUIRE AN ARCHITECT OR STRUCTURAL ENGINEER APPROVAL PRIOR TO INSTALLATION.
4. INSPECT MOUNT AND ANTENNA INSTALLATION EVERY 6 MONTHS (OR AFTER EVERY STORM) FOR TIGHTNESS.
5. ALL ANTENNA INSTALLATION SHOULD BE GROUNDED, BY THE INSTALLER, TO MEET ALL APPLICABLE CODES.

No. ▲ Revision Description		▲ Date		▲ By	
				6	
UNR-Rohn Division of UNR, Inc.					
TYPICAL ROOF REINFORCING FOR TVRO MOUNTS					
Scale: Unless otherwise specified, dimensions are given in inches.					
Drawn by	JSB	Tolerances	3-5/86	Fractions	Angles
Checked by	KA	Dimensions	3-5/86	Finish	Weight
Approved by Engineering	JOB	Material	3-5/86		
Approved by Production	JOB	Date	3-7-85		
Approved by Sales		File Number			
		Date			
		Drawing Number	C050019		