
## FRM

The FRM is a non-penetrating, ballast type roof mount that offers a 30" to 60" mast in sizes ranging from 1-1/4" to 2-3/8" O.D. The base of mount is 34-3/4" square with trays to fit the concrete blocks, typically used as ballast. The mount is galvanized for corrosion protection and goes together quickly. The mount is easily shipped via UPS.



## MAST SPECIFICATIONS

747 (61 61 2611 167 (1161 (6							
Mount Part No.	Mast Part No.	Description					
FRM125	FY202	Tube 1-1/4" x 16 GA. x 60" (PG)					
FRM150	FY203	Tube 1-1/2" x 16 GA. x 30" (PG)					
FRM166	FY204	Tube 1.66" x 16 GA. x 30" (PG)					
FRM238	FY205	Tube 2-3/8" x 14 GA. x 30" (PG)					
FRM225	FY205SP	Tube 2-1/4"x 14 GA.x 60" (PG)					
FRM238SP5	FY205SP	Pipe 2"x SCH40 x 60" (HDG)					

NOTE: The velocities in ( ) apply to the FRM125 mount when strength of the FRM125 mast governs. All other velocities are governed by overturning and apply to all FRM mounts.

## FRM ALLOWABLE ANTENNA AREAS

Effective Projected	Ballast	Zero Velocity Load (PSF)	(Sliding) Vs (MPH)	Vmax at centroid of projected area, (MPH) (Overturning)			
Area (EPA) (FT²)				h=2 FT	h=3 FT	h=4 FT	h=5 FT
2	100 200 300 400	12 24 36 48	140 198 242 280	135 188 222 269	110 153 182 219 (197)	96 133 157 (154) 190	85 119 141 (131) 170
4	100 200 300 400	12 24 36 48	99 140 171 198	96 133 157 190	78 108 129 155 (139)	68 94 111 134(109)	60 84 99 (93) 120
6	100 200 300 400	12 24 36 48	81 114 140 161	78 108 128 155	64 88 105 127 (114)	55 77 91 (89) 110	49 68 81 (76) 98

 $\mathbf{H}$  = Distance from support surface to centroid of EPA.

**Vs** = Effective wind velocity resulting in sliding on a flat surface with a .50 coefficient of friction.

**Vm** = Effective wind velocity based on strength or overturning.

